







1




A.



B.



C.




D.

2




HANDHELD
PORTATIF
EN MANO


B. Optional Extension Wand
Tube-rallonge optionnel
Vara de extensión opcional




UPRIGHT
L'ÉLÉMENT VERTICAL
EN VERTICAL



A.



B.






C.

3



- A. Power Button
Bouton de mise en marche
Botón de encendido
- B. Turbo Mode Button
Bouton de mode turbo
Botón de modo turbo



4

